

# リング枠 (K18・K18WG・K18PG)

画像にある真珠は撮影用の為付属はしていません。



WRK105  
K18  
8mm用



WRK115  
K18  
D:10pcs  
8mm用



WRK124  
K18  
D:2pcs  
8mm用



WRK125  
K18  
D:6pcs  
8mm用



WRK130  
K18  
D:20pcs  
9mm用



WRK117  
K18  
D:14pcs  
10mm用



WRK134  
K18  
D:28pcs  
10mm用



WRK129  
K18  
D:30pcs  
11mm用

**製造中止**



WRK143  
K18  
D:6pcs  
13mm用



WRK162  
K18  
D:6pcs  
3.5~4mm用・芯5



WRK163  
K18  
D:1pc  
3.5~4.5mm用・芯4



WRK164  
K18  
3.5~4mm用・芯5



WRK165  
K18  
5~8mm用・芯3



WRW146  
K18WG  
D:8pcs  
9mm用



WRW137  
K18WG  
D:6pcs  
10mm用



WRW138  
K18WG  
D:4pcs  
10mm用



WRW145  
K18WG  
D:6pcs  
11mm用



WRW148  
K18WG  
D:8pcs  
11mm用

**製造中止**



WRW139  
K18WG  
D:1pc  
9mm・芯2



WRW165  
K18WG  
5~8mm・芯3



WRK157  
K18  
D:14pcs  
4~6mm用



WRW157  
K18WG  
D:14pcs  
4~6mm用



WRPG157  
K18/ピンクゴールド色  
D:14pcs  
4~6mm用